SIGHT MARK®

USER MANUAL

REFLEX SIGHT

Ultra Shot

ABOUT SIGHTMARK®

Sightmark offers a wide range of products that include red dot scopes, reflex sights, rangefinders, riflescopes, laser sights, night vision and award-winning flashlights and boresights. Sightmark products are inspired by military and law enforcement applications. All products are designed to be the most effective weapon accessories possible.

Sightmark - MAKE YOUR MARK

SIGHTMARK®

www.sightmark.com

Ultra Shot reflex sight 1- 5

ENGLISH

ENGLISH

FEATURES:

- Precision accuracy
- InterLok™ internal locking system
- Composite body with metal protective shield
- Reliable and durable
- Wide field of view
- Perfect for rapid fire / moving target shooting
- Multi-reticle (4 patterns)
- Adjustable reticle brightness
- Parallax corrected
- Unlimited eye relief
- Built-in Weaver mount
- Lightweight, water-resistant and shockproof
- Low power consumption

TECHNICAL SPECIFICATIONS

Magnification	(x)	1
Objective	(mm)	34x25
Field of view	(m @ 100yds)	36
Eye relief		infinite
Coating		AR red
Water resistant	(yes / no)	yes
Reticle		multi (4 patterns)
MOA adjustment	(1 click)	1
Power supply; battery type feed voltage	(V)	(1) CR1620 3
Brightness settings		1-5 and "off"
Max recoil	(caliber)	up to .50
Construction		composite body, metal surround
Operating temperature	(C)	-10 to 50
Dimensions	(in)	3.6x1.57x2.1
Weight	(oz)	5.3

INCLUDES:

- Neoprene cover
- Adjustment tools
- Battery
- Limited Lifetime Warranty

DIAGRAM

1. Brightness control
2. Reticle selection
3. Windage
4. Elevation
5. Battery compartment

ABOUT THE SIGHTMARK ULTRA SHOT

The Sightmark series of reflex sights are ergonomically designed to create a lightweight, yet accurate, sight while maintaining all-important peripheral and depth perception while shooting. Perfect for shotguns or rifles, the Sightmark Ultra Shot is able to withstand heavy recoil calibers while being extremely accurate due to its larger, parallax corrected window and dual layers of fused glass that create ultimate precision optics. With a wider field of view than any other reflex sight on the market, oversized viewing area, 4 different illuminated reticle types and a Limited Lifetime Warranty, the Sightmark Ultra Shot is literally in a class by itself.

BATTERIES

The Sightmark Ultra Shot is powered by (1) CR1620, or equivalent, battery. Should the reticle grow dim or not illuminate, the battery needs to be replaced. To install a new battery, unscrew the battery cover on the end of the reticle brightness knob and insert the battery with the + side away from the unit and replace the cover.

MOUNTING

Check to make sure that all included items are present. The sight includes an integrated rail that fits standard Weaver bases, which are suitable for most applications. Due to the unlimited eye relief of the sight, allow at least three inches of clearance between the end of the LED, mirror housing and your eye when shooting.

To mount, loosen the clamp by unscrewing the two large bolts located on the right side of the unit. Place the unit on the rail with the objective facing toward the muzzle and the reticle selection wheel toward the user; adjust as needed. Make sure the sight is sitting flat on top of the rail, and that one of the clamping bolts is located in a recoil groove. When the sight is in place, re-tighten the clamp.

ZEROING

Select the desired reticle by turning the reticle selector knob and set the intensity to a level that is most comfortable for you. With the sight securely mounted, rest the gun on a solid support and aim at a target 50 to 100 yards (or meters) away. All test shots should be made under the same conditions to achieve maximum accuracy – this includes using the same rest and same cartridge type. Fire a test group to see where the gun is shooting. Adjust the reticle accordingly by changing the elevation & windage adjustments until the reticle is zeroed on the point of impact of the bullet. (Note - each click adjustment moves the point of impact by 1 MOA; approximately 1" at 100 yds, ½" at 50 yds).

STORAGE

Make sure that your Sightmark reflex sight is securely attached to your rifle before storing. Be sure to turn the unit off (set the intensity level to zero), and gently clean the lens with the lens cleaning cloth.

WARNING

- Avoid hitting or dropping the unit
- Always unload the weapon before mounting the sight

SIGHTMARK LIMITED WARRANTY

Please visit www.sightmark.com for warranty details and information.

SIGHT MARK®

www.sightmark.com